



Toasters

Prince Castle: Universal Rapid Toasters (340-URT)

When

Daily

Tools

McD® All Purpose Super Concentrate (APSC)

KAYQUAT™ Sanitizer
OR

McD® Sanitizer

McD® Heavy-Duty Degreaser (HDD)

Clean Sanitizer-Soaked Towels

KAY® NO-SCRATCH™ Pad

URT Tool

Heat Resistant Gloves

Sanitizer Spray Bottle

Glass and Multi-Surface Cleaner Spray Bottle

Daily Procedure

1. Turn the unit to “CLEAN” mode by pushing the PRODUCT button and allow unit to reach appropriate temperature.
2. Once toaster has reached clean temperature, turn the unit “OFF” and disconnect power to the unit.
3. Put on heat resistant gloves.

SAFETY: The toaster will be extremely hot and can cause severe burns if handled without using heat resistant gloves.

4. Spray a clean, sanitizer-soaked towel with McD® HDD solution and wipe the top panel to remove soils. A KAY® NO-SCRATCH™ Pad can be utilized for heavy soils. Wipe with another sanitizer-soaked towel to remove cleaner and soil residue.
5. Fold a clean, sanitizer-soaked towel in half and in half again. Wrap the damp, folded towel around the head of the URT Tool.

CAUTION: Do not use abrasive tools, including green scouring pads, on the platens as they will damage the platens.

6. While wearing heat resistant gloves, slowly wipe the platens with the clean, sanitizer-soaked towel on the URT Tool to remove build-up.
7. Spray a clean, sanitizer-soaked towel with McD® HDD solution, wipe the release gates and all areas of the Bun Buffering Landing Zone (BBLZ). A KAY® NO-SCRATCH™ Pad can be utilized for heavy soils on the release gates and BBLZ.

SAFETY: Take caution in reaching the release gates. Do not attempt to clean the release gates through the top of the toaster as burns may result.

8. Wipe the release gates and BBLZ with another clean, sanitizer-soaked towel to remove cleaner and soil residue.
9. Spray McD® Sanitizer solution on all areas of the BBLZ and allow to air dry.
10. Spray a clean, sanitizer-soaked towel with McD® HDD solution and wipe the exterior of the toaster.
11. Reassemble and connect power to the unit.

When

Monthly

Tools*McD® All Purpose Super Concentrate (APSC)**KAYQUAT™ Sanitizer*

OR

*McD® Sanitizer**McD® Heavy-Duty Degreaser (HDD)**McD® Hi-Temp Grill Cleaner**Clean Sanitizer-Soaked Towels**KAY® NO-SCRATCH™ Pad**URT Tool**Breakfast Entrée Base**Heat Resistant Gloves**Sanitizer Spray Bottle**Glass and Multi-Surface Cleaner Spray Bottle***Monthly Procedure**

1. Turn the unit to “CLEAN” mode by pushing the PRODUCT button and allow unit to reach appropriate temperature.
2. Once toaster has reached clean temperature, turn the unit “OFF” and disconnect power to the unit.
3. Put on heat resistant gloves.

SAFETY: The toaster will be extremely hot and can cause severe burns if handled without using heat resistant gloves.

4. Open a packet of McD® Hi-Temp Grill Cleaner and empty the contents onto an entrée base.
5. Firmly attach the KAY® NO-SCRATCH™ Pad to the URT Tool and dip the KAY® NO-SCRATCH™ Pad into the grill cleaner.

CAUTION: Do not use abrasive tools, including green scouring pads, on the platens as they will damage the platens.

6. While wearing heat resistant gloves, carefully spread a light coating of grill cleaner on the top panel. Spread a light coating of grill cleaner on each section of the platen and both sides of the club platen. **DO NOT SCRUB WHILE APPLYING THE PRODUCT.** Wait for 1 – 2 minutes.

CAUTION: Take caution to keep the back of the URT Tool from contacting the platen surface, as scratching may result.

7. After waiting 1 – 2 minutes, scrub the top panel with a KAY® NO-SCRATCH™ Pad until the grill cleaner has liquefied all the soil. Lightly scrub the platen surface with the KAY® NO-SCRATCH™ Pad on the URT Tool until the grill cleaner has liquefied all the soil. For heavy soil, apply additional grill cleaner and lightly scrub.

CAUTION: Take caution to keep the back of the URT Tool from contacting the platen surface, as scratching may result.

8. Remove the KAY® NO-SCRATCH™ Pad from the URT Tool. Fold a clean, sanitizer-soaked towel in half and in half again. Wrap the damp, folded towel around the head of the URT Tool.
9. Remove all the grill cleaner from the top panel by wiping with a clean, sanitizer-soaked towel. Remove all grill cleaner from the platens by wiping with the clean, sanitizer-soaked towel on the URT tool. More than one clean, sanitizer-soaked towel may be needed in order to remove all cleaner and soil residue.

CAUTION: Make certain to remove all cleaner and soil residue from platen surfaces. Residual cleaner or soil residue may lead to bun sticking.

10. While wearing heat resistant gloves, wipe the release gates and BBLZ with a clean, sanitizer-soaked towel to remove all grill cleaner and soils.

SAFETY: Take caution in reaching the release gates. Do not attempt to clean the release gates through the top of the toaster as burns may result.

11. Spray a clean, sanitizer-soaked towel with McD[®] HDD solution, wipe the release gates and all areas of the Bun Buffering Landing Zone (BBLZ). A KAY[®] NO-SCRATCH[™] Pad can be utilized for heavy soils on the release gates and BBLZ.
12. Wipe the release gates and BBLZ with another clean, sanitizer-soaked towel to remove cleaner and soil residue.
13. Spray McD[®] Sanitizer solution on all areas of the BBLZ and allow to air dry.
14. Spray a clean, sanitizer-soaked towel with McD[®] HDD solution and wipe the exterior of the toaster.
15. Reassemble and connect power to the unit.